



Part #122

- Step #1.** This bar is designed to replace your present anti-sway bar with no modification necessary. As you can see, the bar is similar' the only change on some bars is a modification on the contours made necessary by the increase in diameter. It uses the original clamps now on the car. Included are new rubber bushings that will fit in the original brackets.
- Step #2.** After installation, check all fastenings for suitable tightness, and bounce the front of the car to check the clearance of all parts throughout the suspension travel distance. Road test the vehicle and accustom yourself to the car's new handling. For best performance, stability, and balance, use our rear kit #988. As we cannot supervise your installation or driving, we cannot be held responsible for more than the cost of the kit.

Hardware:

| | |
|-----------|-----------|
| 2 RH 008 | End-Links |
| 2 UB 612B | Bushings |
| 2 RH042B | Brackets |
| 2 RH031D | Plates |

8-11-2005

