

DIRECTIONS 333 Toyota Celica 78-86

**Turcel 4 WD 83-86
Corolla 80-86**

*****Rear Wheel Drive OEM Replacement*****

NOTE: If your car does not have a factory rear bar, this bar cannot be mounted because it uses the factory hardware, To mount this bar you must order hardware kit #301.

NOTE: Some Supra Celica's have IRS (independent front suspension). The proper kit for this application is #375. Contact your dealer to exchange kits.

- STEP #1. Remove the existing bar and end-links. FOR YOUR SAFETY! ALWAYS USE CAUTION WHEN WORKING UNDER AN ELEVATED CAR.**
- STEP #2. This kit provides new D-Bushings and brackets. Install the D-Bushings on the mid-section of the bar. Position the bar under the car the same way the old one was mounted.**
- STEP #3. Assemble the end-links to attach the ends of the bar to the eye on the sides of the frame. Tighten the end-links just enough to make the bushings slightly deform.**
- STEP #4. Road test your car to familiarize yourself with its new handling. As we cannot supervise your installation or your driving, we cannot be held responsible for more than the cost of the kit. For best balance, control and stability, this kit should be used in conjunction with one of our front kits.**

HARDWARE

2 RH	014	End-Links
2 RH	042B	Brackets
2 UB	611B	Urethane Bushings